


IMPORTANT
PLEASE DO NOT RETURN TO STORE
If You're Having Trouble, We're Here to Help!




Call us 24/7 at 1-855-292-4087
Email us at support@alteclansing.com or visit us at alteclansing.com




A Closer Look




**Powering On/
Bluetooth
Pairing**



**True Wireless
Pairing**



**Light Change
Mode**



REGISTER YOUR PRODUCT

To receive news, exclusive deals, OTA or firmware updates, warranty information and more please register your product at

alteclansingsupport.com




12 Month Limited Warranty
All Altec Lansing products come with 12 months limited warranty from the date of its original purchase

24 Hour Customer Support
We love our customers, and we care about your experience with Altec Lansing. If you need assistance, please call us at 1-855-292-4087 or e-mail support@alteclansing.com
www.alteclansing.com

In the Box




Charging



Speaker Controls



**Voice Assistant/
Reset**



Overall battery performance varies dependent upon use setting, and environmental conditions. For further information, please visit www.alteclansing.com

FOLLOW US ON



Changes or modifications not expressly approved by the party responsible for compliance could void the warranty. Please refer to the user manual for details. This device complies with Part 15 of the FCC Rules. Operation is subject to the following conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference to other licensed operations. This equipment may cause interference to other licensed operations. However, there is no guarantee that interference will not occur in a particular location. If you experience interference, you are encouraged to take the following steps: 1. Turn the equipment off. 2. Turn the equipment on in a different location. 3. Turn the equipment off and on again. 4. Contact the manufacturer for more information.

— Recipient or relocate the receiving antenna.
— Increase the separation between the equipment and receiver.
— Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
— Consult the dealer or an experienced radio/TV technician for help.

©2023 Altec Lansing Inc.
395 Carter Drive, Newburyport, MA 01887, USA
855-292-4087
www.alteclansing.com